

Laboratory 2

Capacitive circuit voltage control with an industrial controller

1 Preliminary : rules regarding the Covid-19

Please follow carefully the rules mentioned on the website of the UCLouvain: <https://uclouvain.be/fr/decouvrir/mesures-prises-a-l-uclouvain-dans-le-cadre-de-la-covid-19.html>.

The tables of the laboratory enable to keep the distance of 1,5 m between students. Here is a procedure to follow to maximize the health safety while performing the laboratory inside the Euler building:

- Always wear the face mask inside the Euler building;
- Clean your hands with the hydro-alcoholic gel (a dispenser is placed in the corridor);
- Clean your work table with the antistatic cleaning lotion (a dispenser is placed inside the laboratory);
- Clean the keyboard and the mouse of the computer with the IPA (Isopropyl Alcohol) aerosol before starting to work.
- When you finish your work, please clean your work environment with the antistatic cleaning lotion and the keyboard and mouse of the PC with the IPA aerosol before leaving.

For your information, there are toilets where you can wash your hands with soap at both ends of the corridor of the -1 level of the Euler building.

In addition, regarding its own organization, every team of student has to manage any possible impact of a quarantine for one or more student in the team...

2 Introduction

This second laboratory deals with the implementation of a control law in an industrial controller to control a voltage to the terminals of an analog electronic circuit.

Each team of students have 2 time slots of 2 hours (i.e. 4 hours) to perform the experimental part of the laboratory.

The two main interests of this lab are:

- To use of an industrial controller;
- To deal with a system modelled with a nonminimum phase transfer function.

In this document, the equipment overview (i.e. the industrial controller in the section 3 and the electrical circuit in the section 4) are presented first. The instructions for running the experiments come then in the section 6.

Due to the importance of some preliminary calculation, **it is imperative to have prepared the items requested before beginning the laboratory session** dedicated to the experiments with the experimental setup. A printed document with the solutions of the requested calculations will be available in the lab room.

As a reminder, the knowledge of the document titled *General manual for the labs and the tutorials sessions* is a **prerequisite for performing the laboratories**.



Figure 1: Experimental setup

3 Presentation of the industrial controller

3.1 General considerations

Different types of industrial controllers are available in the industrial environment.

In some cases, as part of some modern industrial processes, controllers of PID type are presents as algorithms computed in an Programmable Logic Controller (PLC).

In other cases for more simple or more specific processes, there exist controllers available as preprogrammed equipment, with fixed inputs and/or outputs or partially configurable. This type of controllers will be used for this laboratory.

From a "packaging" point of view, PLCs as partially configurable controllers have the form of a box, meeting the applicable standards, and containing the electronics to compute the control law or the value of the control signal. These cases usually only have as user interface some lights indicators and alpha-numeric displays. Computers or specific console interfaces are then necessary to program these devices, as well as the monitoring of processed data.

3.2 The selected PID controller

The controller selected for this lab is a partially configurable PID type controller designed and produced by OMRON. It is representative of the market offer for this type of devices. When the experimental system of the laboratory has been designed, it was one of the most general version, i.e. it accepts as I/O unspecified electronic signals (voltage between 0 and 10 Volts, and currents between 0 or 4 and 20 mA). Other models offered more oriented I/O such that thermocouple inputs, relays or triacs output.

Beside its PID controller function, the selected device is also equipped with threshold alarm and a list of other customizable functions, scale changes, signal filtering and more. All the parameters of these functions have to be encoded via a front panel consisting of a digital indicator and some buttons (a drop down menu is supposed to simplify the task of the user...).

For this laboratory, a control and monitoring software has been developed to enable students to communicate with the controller, to simply set the important parameters and graphically display the signals of process value and control action. The synoptic of the software is largely inspired by the front panel of the controller.




Figure 2: Case containing the OMRON controller and the circuit of the system

3.3 The supervision and command software

This software has to be downloaded from the *Moodle* site of this course (file `Labo_Omron-app.zip`).

For a proper operation of the software, it is recommended to follow the procedure below:

1. Select the file `Labo_OMRON-app.zip`, and download it;
2. Save it on the network disk `Z:\`;
3. Right click on the file `Z:\Labo_Omron-app.zip` and select "*Extract all*". Windows will extract all the `.zip` file in a new file `Z:\Labo_Omron-app` that it will create;
4. To run the software of the lab, you must double click on `Z:\Labo_Omron-app\OMRON.exe`.

To communicate with the industrial controller (with the right communication parameters), the software needs the 3 other files that come with it.

When the software is running, the three panels presented on the figure 3 must be active, and one of them gets the data displayed on the front panel of the controller.

3.3.1 Front panel of the controller

This panel of the software (see figure 3) reflects the state of the main information stored and displayed by the industrial controller on its front panel:

- **PV** : Process Value
State of the measure, expressed in % of the scale (0 - 10 V).
- **SP** : Set Point
Setpoint value, expressed in % of the scale (0 - 10 V ou 0 - 20 mA). **If the feedback loop is activated (the indicator RUN is ON), it is the setpoint, else, it is the control signal, directly applied on the process.**




Figure 3: View of the user interface of the control and monitoring software used for this lab

- **MV** : Manipulated Variable
State of the control input, expressed in % of the scale (0 - 20 mA).
- **PB** : Proportional Band
Inverse of the proportional gain of the controller, without unit.
- **Ti** : Integral Time
Integration constant, in seconds.
- **Td** : Derivative Time
Derivative constant, in seconds.
- **A11, A12, A13** : Alarm indicators. Not used.
- **RMT**: ReMoTe
Indicator of remote control. ON if the the controller can be programmed via a RS-232 connection with the computer (not used, and forced to active state).
- **MANU** : Manual
Indicator ON if the controller is in manual mode (not used and forced to inactive state).
- **RUN** : Indicator of feedback control (i.e. closed loop), ON if the feedback control loop is active (the system is in open loop if the indicator is OFF).

3.3.2 Remote control panel

This panel allows to modify control parameters used for this lab, and to communicate them to the controller. This panel is divided in 3 different sections and separately changeable:

- One section for the setpoint (SP);
- One section for the control parameters (PB, Ti et Td);
- And one section for the operating mode (RUN).

To modify one parameter and to send it to the industrial controller, students must first change the value in the digital control in the lab software. And to send it to the controller, students must click on the associated **"Send command"** pushbuttons.

3.3.3 Panel of the graphical plot

This last panel contains a graphical plotter that shows the evolution of the data with the time. The different data can be identified with the associated legend.

The graphical plotter runs in scan mode on a time scale of 100 seconds. The display is scanned twice before being cleared to restart. For a good view, the most significant changes will have to occur in the first 100 seconds of an experiment.

The software store 200 seconds of data in buffer that can be recorded in a file for a later examination.

Beside the graphic plotter itself, the panel also contains:

- A timer with a resolution of one second. This timer is automatically reset after 200 seconds.
- A **STORE** button that activate the record procedure of the buffer in which the data are stored. The data are then recorded as an **ASCII** array organized in columns separated by tab characters. From left to right, the columns exhibit the time [s] and the variables SP [%], MV [%] et PV [%]. The procedure provides a classic *Windows* recording menu. **Warning :** The data can only be recorded on the drive Z: or on a USB memory stick. All the other memory locations of the computers can be cleared at the next reboot.
- An **ERASE** button that clears the plotter, resets the data memory buffer and restarts an observation of 200 seconds.
- An **EXIT** button to stop and exit the session.

4 The system used for this laboratory

4.1 The electronic circuit

The system used for this lab is a simple capacitive circuit whose diagram is shown on figure 4.




Figure 4: Electronic circuit of the lab system

The control signal from the OMRON controller is a current (i) between 0 and 20 mA, and the output is an analog voltage (V_A or V_B) between 0 and 10 V.

The printed circuit board contains 3 resistors, 2 capacitors and a small analog circuit that computes the arithmetic operation shown as a block diagram on figure 4.

The Sw_m switch selects the output voltage, either the "natural" voltage of the capacitive circuit (V_A [V]), or the voltage from the analog computing (V_B [V]). This is the position of this switch that introduce the unstable zero in the transfer function of the system.

The Sw_p switch allows to connect/disconnect two resistors in parallel, which serve like a disturbance for the system.

4.2 Equations of the circuit

The behaviour of the circuit can be fully modelled using the equations of electric circuits.

Balance of currents :

$$i_{C1} = i - i_{rp} - i_{R12} \quad (1)$$

$$i_{C2} = i_{R12} \quad (2)$$

Components equations :

$$\frac{dV_1}{dt} = \frac{1}{C_1} i_{C1} \quad (3)$$

$$i_{R12} = \frac{V_1 - V_2}{R_{12}} \quad (4)$$

With the equations (1), (2), (3) and (4), we can find:

$$\frac{dV_1}{dt} = \frac{-1}{C_1} \left(\frac{1}{R_p} + \frac{1}{R_{12}} \right) V_1 + \frac{1}{C_1} \frac{V_2}{R_{12}} + \frac{i}{C_1} \quad (5)$$

$$\frac{dV_2}{dt} = \frac{1}{C_1} \frac{1}{R_{12}} V_1 - \frac{1}{C_2} \frac{1}{R_{12}} V_2 \quad (6)$$

$$V_a = V_2 \quad \text{ou} \quad V_B = -V_1 + 2V_2 \quad (7)$$

$$(8)$$

4.3 Scaling

The OMRON controller expresses its I/O variables in% of full scale. This facilitates the fact that the same device can be equipped with several electronic adaptation modules for different physical quantity (temperature, voltage, current, impedance, ...). In our case, we have to proceed with the following changes:
The control parameter :

$$[0mA; 20mA] \Leftrightarrow [0\%; 100\%] \quad (9)$$

$$\text{d'où :} \quad i_{[mA]} = i_{\%} \frac{20}{100} \quad (10)$$

Output variable:

$$[0V; 10V] \Leftrightarrow [0\%; 100\%] \quad (11)$$

$$\text{d'où :} \quad V_{A \text{ ou } B[V]} = V_{A \text{ ou } B\%} \frac{10}{100} \quad (12)$$

From equations (5), (6) et (7) it is now possible to write the state equations under the following form:

$$\frac{dV_1}{dt} = \frac{-1}{C_1} \left(\frac{1}{R_p} + \frac{1}{R_{12}} \right) V_1 + \frac{1}{C_1} \frac{V_2}{R_{12}} + \frac{0,2}{C_1} i_{\%} = f_1(i_{\%}; R_p; V_1; V_2) \quad (13)$$

$$\frac{dV_2}{dt} = \frac{1}{C_1} \frac{1}{R_{12}} V_1 - \frac{1}{C_2} \frac{1}{R_{12}} V_2 = f_2(V_1; V_2) \quad (14)$$

$$V_{a\%} = 10V_2 \quad \text{ou} \quad V_{B\%} = -10V_1 + 20V_2 \quad (15)$$

4.4 Linearised state equations

The disturbance is the resistor R_p [Ω]. Thereby the state equations are nonlinear. It is therefore necessary to find an operating point (= equilibrium) ($i_{\%}^-; \bar{R}_p \Rightarrow \bar{V}_1; \bar{V}_2$) in the neighbourhood of which the system can be considered to be linear.

Thereafter the usual notations will be used, namely:

$$i_{\%}^- \rightarrow u \quad (16)$$

$$\bar{R}_p \rightarrow v \quad (17)$$

$$\bar{V}_1 \rightarrow x_1 \quad (18)$$

$$\bar{V}_2 \rightarrow x_2 \quad (19)$$

$$V_{A \text{ ou } B\%} \rightarrow y \quad (20)$$

$$(21)$$

and the positive counted parameters $a_{11}; a_{12}; a_{21}; a_{22}; b$ and d , given by :

$$a_{11} = \left. \frac{\delta f_1}{\delta V_1} \right|_{\bar{V}_1} = \frac{1}{C_1} \left(\frac{1}{\bar{R}_p} + \frac{1}{R_{12}} \right) \quad a_{12} = \left. \frac{\delta f_1}{\delta V_2} \right|_{\bar{V}_2} = \frac{1}{C_1 R_{12}} \quad (22)$$

$$a_{21} = \left. \frac{\delta f_2}{\delta V_1} \right|_{\bar{V}_1} = \frac{1}{C_1 R_{12}} \quad a_{22} = \left. \frac{\delta f_2}{\delta V_2} \right|_{\bar{V}_2} = \frac{1}{C_2 R_{12}} \quad (23)$$

$$b = \left. \frac{\delta f_1}{\delta i_{\%}} \right|_{i_{\%}^-} = \frac{0,2}{C_1} \quad d = \left. \frac{\delta f_1}{\delta R_p} \right|_{\bar{R}_p} = \frac{\bar{V}_1}{C_1 \bar{R}_p^2} \quad (24)$$

These parameters are those of the general equations given below:

$$\dot{x}_1 = -a_{11}x_1 + a_{12}x_2 + bu + dv \quad (25)$$

$$\dot{x}_2 = a_{21}x_1 - a_{22}x_2 \quad (26)$$

$$y = 10x_2 \quad \text{ou} \quad (-10x_1 + 20x_2) \quad (27)$$

For reasons of **digital simplifications**, it is advised for students to work with electrical quantities expressed in $k\Omega$ and in mF .

5 Structure of the OMRON controller

The manufacturer of the controller used in the context of this lab considers the PID structure of the controller shown on figure 5.




Figure 5: PID structure of the OMRON controller

The control input is given by:

$$u = \frac{100}{PB} \left(\left((1 - \alpha) + \frac{1}{sT_i} \right) \epsilon - sT_d \cdot y \right)$$

Users of this PID controller must note that:

- The proportional gain has the form of $\frac{100}{PB}$. The acronym PB reads *Proportional Band* and is expressed in %.
- The integral and derivative gains are expressed in seconds.
- An α factor, without units, has been introduced by the manufacturer. This factor has the effect of reducing the term of the instantaneous response to an abrupt change of setpoint. This setting is tunable in the interval $[0; 1]$. Although this device may be useful, it will be constantly forced to 0 in the context of this lab to keep a conventional structure.

- The PB , T_i and T_d parameters are bounded by the manufacturer:

$$PB \in [0, 1; 999, 9] \% \quad (28)$$

$$T_i \in [1; 3999] \text{ s} \quad (29)$$

$$T_d \in [1; 3999] \text{ s} \quad (30)$$

6 Experiments to achieve for this laboratory

6.1 Usage restrictions

For this laboratory, the derivative action will not be used. We must therefore ensure that the value $T_d = 0$ is effective. The transfer function of the controller is therefore:

$$C(s) = \frac{100}{PB} \left(1 + \frac{1}{s.T_i} \right)$$

6.2 Linearisation

In order to linearise the system equations, a reference equilibrium point has to be given. It is advised to use the point:

$$\bar{i}_{\%} = 50 \% \quad \bar{R}_p = R_1 = 0,47 \text{ k}\Omega \quad (31)$$

All parameters are now computable.

Before any other experiment, the system has to be brought to the reference point. To perform this preliminary experiment, you must:

1. Deactivate the **RUN** mode;
2. Place **SW phase** switch (switch of mode) in position **A** (to disconnect the analog computing module);
3. Place the **SW pertu** switch (disturbance switch) in position **A** (only R_1 connected);
4. Set a setpoint (**SP**) of 50 %;
5. Let the system settling down.

6.3 Settling time measurements

Before calculating the parameters of the controller, students must be able to characterize the dynamics of the system. For an open loop stable system like the one used in this lab, one of the main feature is the settling time or the response.

The goal of the present experiments is to measure the settling time with a step of disturbance and this, for the two modes of operation: without zero ("minimum phase" mode), and with an unstable zero (in "nonminimum phase" mode). This experiment will enable to observe that, despite the difference in the transient responses, both versions of the system have the same settling time.

6.3.1 Measurement with the "minimum phase" system

To perform this experiment, the procedure is as follows:

1. Initially place the system in open loop;
2. Place the system at its reference point;

3. Click on the **Erase** button;
4. After 10 seconds, toggle the **SW pertu** switch from position A to position B;
5. Let the system evolve and record the transient response of the system while the system is returning to its equilibrium. Subsequently, store the data and measure the response time.

6.3.2 Measurement with the "nonminimum phase" system

To perform this second experiment, the procedure is as follows:

1. Initially place the system in open loop;
2. Place the system at its reference point;
3. Toggle the switch **SW phase** from position A to position B (to connect the analog computer);
4. Let the system evolve to its equilibrium (needed given the energy transfer induced by the switch of mode);
5. Click on the **ERASE** button;
6. After 10 seconds, toggle the **SW pertu** switch from position A to position B;
7. Let the system evolve and record the transient response of the system while the system is returning to its equilibrium. Subsequently, store the data and measure the response time.

6.4 Correction of a disturbance step

The compensation of a disturbance step is the main goal of this type of controller. Indeed, the change of setpoint are occasional, and for the most of the time, a controller maintains the system at the fixed setpoint value, despite the disturbing external events.

For the three experiments listed below, students have to calculate the values of the parameters PB and T_i .

6.4.1 "Minimum phase" system

If the transfer function "*disturbance* \rightarrow *output*" has been correctly derived, the $T_{vmp}(s)$ transfer function has a 3rd order denominator. Students have to place the poles of the $T_{vmp}(s)$ transfer function (so the controller parameters) to have a settling time similar to the natural settling time (of the system in open loop). In other words, students must fix one of the 3 poles, the value of the slowest pole of the system, and to place the others on the left (with a more negative real part). The response has to be non-oscillating.

To test the response of the closed loop system with the parameters of the controller, students have to follow this procedure:

1. Place the system in open loop;
2. Place the system at its reference point;
3. Enter and send the calculated PB and T_i parameters;
4. Activate the **RUN** mode (that close the loop by computing the error);
5. Click on the **ERASE** button;

6. After 10 seconds, toggle the SW **pertu** switch from position A to position B to apply a disturbance;
7. Let the system evolve and record the transient response. Subsequently, store the data and measure the settling time.

6.4.2 "Nonminimum phase" system

To test the parameters tested on the previous paragraph but on the nonminimum phase system, students have to:

1. Stay on the RUN mode;
2. Place the system at its reference point;
3. Do not change the values PB neither T_i ;
4. Toggle the SW **phase** switch from position A to position B (to connect the analog computer that generates the unstable zero).

The "nonminimum phase" system controlled with the PB and T_i parameters gives an unstable closed loop system. The examination of the transfer function immediately gives the explanation ...

6.4.3 Stable "nonminimum phase" system

First, students have to derive the transfer function of the chain "controller - system", without the unit feedback of the output. This chain is the key of the closed loop transfer function " $setpoint \leftarrow output$ ". To use the zero of the controller to compensate one of the poles of the open loop system looks a priori as a good choice.

It is necessary to choose the slowest pole, because its action is dominating the open loop dynamics. This choice is also perfectly justified to set the settling time of the system in relation to a setpoint step.

The pole-zero cancellation explained above allows to calculate T_i . The value of PB can be calculated by formulating the followings constraints:

- The disturbance step response of the system must be stable;
- The disturbance step response of the system must not present any overshoot;

To test the calculated parameters, it is advised to:

1. Place the system in open loop;
2. Place the system at its point of reference;
3. Enter and send the calculated values of the PB and T_i parameters;
4. Toggle the SW **phase** switch from position A to position B;
5. Activate the RUN mode;
6. Click on the ERASE button;
7. After 10 seconds, toggle the SW **pertu** switch from position A to position B;

8. Let the system evolve and record the transient response while the system is returning to its equilibrium. Subsequently, store the data and measure the response time.

6.5 Setpoint step response in "nonminimum phase" mode

For completeness, it remains to observe the behaviour of the system reacting to a step applied on the setpoint, with the values of the PB and T_i parameters of the previous paragraph.

Students have to follow this procedure:

1. Let the system in closed loop (RUN mode activated) at the point of reference;
2. The SW **phase** switch must be in position B and the SW **pertu** switch in position A;
3. Keep the values of the PB et T_i parameters calculated in the previous paragraph;
4. Enter a setpoint of $SP = 40 \%$ without sending it;
5. Click on the **ERASE** button;
6. After 10 seconds, send the setpoint value to the controller;
7. Let the system evolve and record the transient response while the system is returning to its equilibrium (correcting the error). Subsequently, store the data and measure the response time.

7 Preparation for the lab session

Given the complexity of calculations, the students are advised to prepare the following points before performing the experiments:

1. Calculate the numerical values of the parameters: a_{11} ; a_{12} ; a_{21} ; a_{22} ; b ; d ; \bar{V}_1 and \bar{V}_2 ;
2. Calculate the symbolic (simplified and factorized) and numerical equations of the transfer functions $G(s)$ and $H(s)$ of the "minimum" and "nonminimum phase" system;
3. Calculate the symbolic equations (simplified and factorized) of the transfer functions $T_v(s)$ of the "minimum" and "nonminimum" phase system;
4. Calculate the symbolic equation (simplified and factorized) of the "nonminimum phase" transfer function $T_r(s)$.

An additional paper will be available at the laboratory.

8 Assessment preparation

For the lab assessment, it is necessary to perform the test with the software `Labo_OMRON_2021_eval_vX.exe` (that will be available after the spring holidays). This software requires the student's FGS number, asks randomly selected questions and returns a numerical key. This **personal key is needed for the individual lab assessment**.

Moreover, to be better prepared for this assessment at the end of the course, it is advised to understand and prepare responses to the following statements:

1. Be able to provide all the block diagrams of the controlled systems and be able to show the links

with the components of the experimental system;

2. Be able to provide all the symbolic and numerical calculations of all the expressions used for this lab;
3. Be able to graphically describe the open loop transient response of the 2 operational modes of the system;
4. Be able to measure and criticize the values of the different settling time encountered in this lab;
5. Be able to provide and justify all the calculations of the control parameters encountered in this lab;
6. Be able to justify the failure of control in paragraph 6.4.2;